


DEPGHW

Einhand-AP-Badebatterie derby plus mit Hebel geschl. o. Brausegarn. Verchr. VIG

Bath mixer derby plus with lever close without shower set ch.VIGOUR

YVG7340005	Hebel derby plus für Wandbatterie VIGOUR	Handle derby plus for wall mounted mixer VIGOUR
YVG7339505	Wandarmaturenanschluss derby/derby style AP-Bade- und Brausebatterie VIGOUR	Union nut for derby/derby style Surface-mounted shower/bath mixer VIGOUR
YVG7343805	Umstellung derby für AP-Badebatterie und Standardarmatur Wanne VIGOUR	Diverter derby surface-mount. finish set floor standing bath mixer VIGOUR
YVG7421805	Rosette derby / derby style / derby plus für Aufputzbatterien VIGOUR	Escutcheon derby /derby style/derby plus for surface mounted mixers VIGOUR
YVG7560700	Keramik Kartusche Ø36mm für derby und derby style Armaturen VIGOUR	Ceramic cartridge Ø36mm for derby and derby style faucets VIGOUR
YVG7601805	Care-Strahlregler M24x1 für derby plus Armaturen VIGOUR	Care aerator M24x1 for derby plus for VIGOUR faucets
YVG7504500	Rückflussverhin.derby / derby style f. Dreiloch-WT, Einh. AP-Badebatt VIGOUR	Non return valve derby / derby style 3-hole basin and surf.moun. single lever
YVG7655100	S-Anschluss für derby / derby style Armaturen VIGOUR	S-Unions for derby / derby style Faucets VIGOUR
YVG92204600	Gewindestift derby / derby style für Farbset Waschtischbatt. VIGOUR	Set screw derby / derby style Finish set for basin mixer VIGOUR
YVG93013000	Spannschraube derby / derby plus Einh.Spültisch- u. Waschtischbatt.VIGOUR	Locking screw derby / derby style single lever sink and basin mixer VIGOUR
YVG93089705B	Markierungsstopfen derby / derby style Armaturen VIGOUR	Marking plug derby / derby style for VIGOUR faucets



DEPGHW

Einhand-AP-Badebatterie derby plus mit Hebel geschl. o. Brausegarn. Verchr. VIG

Bath mixer derby plus with lever close without shower set ch.VIGOUR

YVG93090805	Abdeckkappe derby / derby style für Waschtischbatt. VIGOUR	Cover cap derby / derby style for basin mixer VIGOUR