



DESB

Einhand-AP-Brausebatterie derby style
ohne Brausegarnitur verchromt VIGOUR

Surface-mounted shower mixer derby style
without Shower set chromed VIGOUR

| | | |
|--------------|---|---|
| YVG7338405 | Hebel derby style für AP-Badebatterie VIGOUR | Lever derby style conc. shower mixer VIGOUR |
| YVG7345205 | Wandarmaturenanschluss derby/derby plus für Einh.- Wandbatt. VIGOUR | Union nut for derby / derby plus for wall mounted single lever VIGOUR |
| YVG7421805 | Rosette derby / derby style / derby plus für Aufputzbatterien VIGOUR | Escutcheon derby /derby style/derby plus for surface mounted mixers VIGOUR |
| YVG7510600 | Rückflussverhind. derby style / Safe-Tec Einh.- AP-Brause- u. Spültischbat.VIGOUR | Non return valve derby style /Safe-Tec Surface mounted shower, and sink mixer |
| YVG7560700 | Keramik Kartusche Ø36mm für derby und derby style Armaturen VIGOUR | Ceramic cartridge Ø36mm for derby and derby style faucets VIGOUR |
| YVG7655100 | S-Anschluss für derby / derby style Armaturen VIGOUR | S-Unions for derby / derby style Faucets VIGOUR |
| YVG92204600 | Gewindestift derby / derby style für Farbset Waschtischbatt. VIGOUR | Set screw derby / derby style Finish set for basin mixer VIGOUR |
| YVG93013000 | Spannschraube derby / derby plus Einh.Spültisch- u. Waschtischbatt.VIGOUR | Locking screw derby / derby style single lever sink and basin mixer VIGOUR |
| YVG93089705B | Markierungsstopfen derby / derby style Armaturen VIGOUR | Marking plug derby / derby style for VIGOUR faucets |
| YVG93090805 | Abdeckkappe derby / derby style für Waschtischbatt. VIGOUR | Cover cap derby / derby style for basin mixer VIGOUR |
| | | |